

MUNOX / Blu-Bio PROGRAMMING DOSAGE

For model Stenner Peristaltic pump models:

E10T1F, E1011F81S4.

The program is as follows:

To set the Event On / Off time Dosage.

Plug in unit. Remove the small Phillip's screw holding on the pump controller screen cover and slide the splash cover off.

At the start of each event Press **TIMER**, set **DAY** to all days showing on the screen.

Event 1: (set **DAY** to all) Press **HOUR**, set 2 AM for start, press **TIMER**, set 3 AM for stop (1 hour = 3 oz.)

Event 2: (set **DAY** to all) Repeat 07:00 - 08:00

Event 3: (set **DAY** to all) Repeat 1200 - 1300

Event 4: (set **DAY** to all) Repeat 1700 - 1800

Replace slide on splash cover and screw.

The recommended dosage for 4000 to 5000 gallons is 10 to 12 ounces per day.

Add or remove events as needed for tank sizing.

There is a battery inside the unit that stores the program in case power is interrupted.